

# **Glassware Washer Automatic Digital Bosch**

## **14 Place Settings Machine 84x60x60cm Abron AC-365GDB2**



- 14 Place Settings Suitable for all uses
- operate your washer from anywhere using a smartphone or voice assistant device for an easier everyday life
- Eco Silence Drive: especially energy-saving and silent in operation with a particularly high life span.
- 3 stage Rack matic design: adjustable baskets provide flexibility in loading glassware porcelain stainless steel material lab items
- 6 programmes: Intensive 70 °C,
- Express Sparkle 65 °C,
- Auto 45-65 °C, Eco 50 °C,
- Custom programme
- Save Water washer uses 9.5 litre of water.
- While manual washing uses minimum 60 litres of water,
- Save time - Get clean & dried utensils in just 59 minutes
- Dimensions (HxWxD): 84.5 x 60 x 60 cm